

# Hydrant Setup

## Table of Contents

Introduction .....	2
Hydrant Type .....	2
Hydrant Status .....	2
NFPA Class .....	2

### Introduction

This chapter describes how to setup the hydrant module. Access the hydrant setup functions by first clicking the drip down arrow on the right side of the hydrant icon.

### Hydrant Type

Select this tab to enter the hydrant types.

### Hydrant Status

Select this tab to enter the hydrant status types.

### NFPA Class

Select this tab to enter the NFPA class. The following screen shot are the recommended NFPA classes.

